



- 1. Filter Holder
- 2. O ring
- 3. Filter (disc)
- 4. Filter Spring
- 5. Orifice Assy.
- 6 & 24. O ring
- 7. Retainer
- 8. Inlet
- 9. Fuel Line
- 10. Pump Body
- 11. Label, RH

- 25. Contact Screw
- 26. Contact Spring
- 27. Socket
- 28. Spark Plug
- 29. Assy Screws
- 30. Combuster
- 31. Button
- 32. Flameholder
- 33. O ring
- 34. Strap
- 35. Button Spring

- | | | | |
|----------|------------------------------|-------|--------------------------|
| 12. | Label, LH | 36A. | Hose Assy-US (Not shown) |
| 14. | Name Plate, Euro (Not shown) | 37. | Regulator (Not shown) |
| 15. | Housing, RH | 38-1. | POL Fitting (Not shown) |
| 16. | Housing, LH | 39. | Gauge (Not shown) |
| 17 & 18. | Trigger/Igniter Assy | 40. | Metal Box (Not shown) |
| 20. | Safety | 41. | Guard Screw |
| 21. | Spring | 43A. | UL Guard |
| 22. | Valve Assy | 44A. | Wrench-US (Not shown) |
| 23A. | Hose Adapter-US | | |